

Chemical Adhesive Station

Adhesives are available throughout Bray such as tape, craft glue and wood glue.

The Machine Shop contains specialized adhesives. These items may only be used under the supervision of Machine Shop personnel. No outside chemicals, including adhesives, may be brought into Bray.

Safe Location

Materials Lab (Room 113) Chemical Hood

Safe Attire

Should be worn:

- Safety glasses
- Gloves
- Lab coat

Safe Operation

- Fume hood sash must be as low as possible
- Check in with Shop Supervisor (Ben Ginden) to learn specific procedure.

Emergency Procedure

- Notification of Fabrication Supervisor (Ben) or Lab Coordinator (Marya) immediately
- If exposed to skin: wash effected area

Severe injury such as exposure to face/eyes

- Notification of Public Safety and TEHS Immediately via 617-627-6911
- Immediately flush face with eyewash for 15 minutes

Cleanup

- Wipe down surfaces.
- Allow excess to dry under the hood before throwing away.
- Put adhesive, glasses, gloves and lab coat away.